






Description		DS6600	DS6600-M9
Restore default setting			
Beep On			
Beep Off			
Language Keyboard	English (QWERTY)		
	French (AZERTY)		
	German (QWERTZ)		
	Spanish		
	Italian		
	Dutch		
	Russian		
	Portuguese		
	Sweden		
	Japanese		
	Turkish-Q		
	Turkish-F		